


MODES OF USE

1 DISSUASION MODE


Triggering of the electric pulse by electro-magnetic sensor



DISSUASION (remotely): Move your thumb towards your index finger to activate **arming**. After 2 seconds, the electrical impulse will be triggered. (**Triggering**).

2 CONTACT MODE

Triggering of the electric impulse by contact button



CONTACT (sur individu): Grab the assailant, avoiding the areas considered dangerous (eyes/jugular/testicles). Upon contact of the glove with the assailant, the contact button located in the middle of the palm of the hand will trigger the electrical impulse (**Triggering**).

